

1. Assemble Plastic Base and Metal Plate.
2. Place Gooseneck into the mounting hole of plastic base assembly.
3. Attach wing nut to the thread of Gooseneck at the bottom of plastic base assembly.

