


1. Right-click on [EzUtility_7.05.exe](#) and tick 'Run this program as an administrator' in the pop-up menu. Complete the installation by double-clicking on the [EzUtility_7.05.exe](#).




2. After successful installation, please also right-click on the shortcut icon of [Ez Utility](#) on the desktop and tick 'Run this program as an administrator' in the pop-up menu.



3. Connect the scanner and the host with USB cable.
4. Scan [\[.C008\\$\]USB-HID](#) below to switch to USB-HID interface.



- Run **Ez Utility**, select Product Type as appropriate (see below Table 1 for details), select “**USB-HID**” as Interface, keep Time out as is, and click [Save-Exit (S)] to continue.



< Table 1: Product Type & Corresponding Models >

Product Type	Corresponding Model(s)
New Models	
New	MT15,MT6225,MT8300,MT830(M),MT8600V, MT6250,MT850,MT8250P,MT8210P,MT8225, MT581,MT584(M),MT582(M),MT840,MT500,MT820(M) MT412/MT5300/MT52501 (FW: HM3-b-x.xx.R) MT10 (FW: HM3-d-x.xx.R) MT1095 (FW: HM3-c-x.xx.R) MT8010 (FW: HM3-e-x.xx.H1) MT30/MT40(W) (FW: SM3-k-2.xx, HM3-k-x.xx.R) MT780 (FW:HM3-e-x.xx, HM3-e-x.xx.R) MT1227L (FW: HM3-h-x.xx.BTA) MT100A (FW: HM3-c-x.xx.BTA) MT110(M) (FW: HM3-c-x.xx.BTA.M1) MT110L(M) (FW: HM3-c-x.xx.BTA.LS)
Legacy/EOL Models	
General	MT6600H,MT3000,MT2000 MT412/MT5300/MT52501 (FW: FM3-b-x.xx) MT1095 (FW: SM3-c-x.xx) MT8010 (FW: SM3-e-x.xx.H1) MT7950TA,MT3000L,MT2000L
Engine	MT700,MT710D,MT742(L),MT752(L),MT712LR-III, MT10 (FW: SM3-d-x.xx) MT30 (FW: SM3-j-1.xx) MT40(W)(FW: SM3-k-1.xx) MT780 (FW:SM3-e-x.xx)
1D-Fixed	MT6220

10. Scan one of the configuration barcodes below to reset the scanner back to the desired interface:




BT HID



BT SPP



Memory Mode



USB HID



USB VCP